

**MOTOROLA**

MX300 Series

Parts List

MX320, MX330, MX340, MX350, MX360, H23AAU, H24AAU, H33AAU, H43AAU, H44AAU

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
2	NLN7311A	Back Cover Kit (320)	41	0282653D03	Nut, Mounting (1/4-32)	66	0405555C02	Washer, Thrust
	NLN7312A	Back Cover Kit (330)		0282653D05	Nut, Mounting (1/4-28)	67	0205344C02	Nut, Special
	NLN7313A	Back Cover Kit (340)	42	0300138661	Screw	70	0305857C01	Screw Cap
	NLN7314A	Back Cover Kit (350)	43	0105953C37	Power Flex Circuit (320)	71	0482799H04	Washer, Insulator
	NLN7315A	Back Cover Kit (360)		0105953C38	Power Flex Circuit (330)	73	0205256C02	Screw
3	0382210E15	Screw, Captive		0105953C39	Power Flex Circuit (340)	74	3605577C01	Knob
4	0405465C01	Washer Seal		0105953C40	Power Flex Circuit (350)	75	0405342C01	Washer, Thrust
5	0405818D01	Washer		0105953C41	Power Flex Circuit (360)	76	NAD6283A	Antenna (150.8-162 MHz)
6	3282172J11	Gasket "O" Ring (320)	44	1405424D04	Insulator (.21" x .21")		NAD6284A	Antenna (162-174 MHz)
		Gasket "O" Ring (330)		1482302E05	Insulator (.31" x .31")			Antenna (403-430 MHz)
		Gasket "O" Ring (340)	45	0205543E01	Nut Mounting			Antenna (440-470 MHz)
		Gasket "O" Ring (350)	46	2905548E01	Lug, Antenna			Antenna (470-512 MHz)
		Gasket "O" Ring (360)	48	RPX4624A	Frame (320)	77	3205701C03	"O" Ring
7	0105952G99	Nut, Retainer Special		RPX4625A	Frame (330)	78	4805504C01	(CR303) Diode
8	6405535D06	Plate, Ground Shield (320)		RPX4626A	Frame (340)	79	1405545E01	Insulator
		Plate, Ground Shield (330)		RPX4627A	Frame (350)	82	2605767C05	Shield Jack
		Plate, Ground Shield (340)		RPX4628A	Frame (360)	83	0484345A06	Washer
		Plate, Ground Shield (350)	49	0305466C01	Screw Slotted	84	0905505C02	Antenna Jack
		Plate, Ground Shield (360)			(180 Special Head)			(.135 ground term.)
9	1505673C01	Housing, Connector		0305466C02	Screw Slotted		0905537F02	Antenna Jack
10	3205427C04	Boot			(219 Standard Head)			(.161 ground term.)
11	4505509C03	Actuator	50	0400009743	Washer, #4, Split	85	0105585H01	Plug Spring and Insulator
13	4105414C01	Spring	51	0705423C01	Bracket, Ring	87	7505585C01	Pad, Pressure
14	5505417C01	Latch battery			(Low & Medium Power)	88	4082159D01	Switch Ptt
15	RPX4241A	Base, Frame Support		0705875C01	Bracket, Ring (High Power)	91	3905188D03	Spring Grounding
16	0704830C02	Support, Battery Contact	52	5005181E02	Speaker	92	8405812C01	Flex Circuit Interconnect
17	RPX4636A	Contact, Battery	53	3505866N01	Cover Speaker Felt			(1-2 Freq.)
18	0300138651	Screw & Lockwasher	54	0105953B83	Cover & Grille (320)		8405111D01	Flex Circuit Interconnect
20	6500139554	Fuse Cartridge		0105957B51	Cover & Grille (330)			(4 Freq.)
21	3805881D01	Cap Fuse		0105959B38	Cover & Grille (340)		8405112D01	Flex Circuit Interconnect
22	NLN4171B	Flex Circuit Control		0105959B39	Cover & Grille (350)			(6-8 Freq.)
23	0905552D01	Connector J303		0105959B40	Cover & Grille (360)	94	NLD6881A	Switch & Flex, VHF, 4F
24	0905675C01	Socket J302	55	2805551D01	Plug (High Power)		NLD6891A	Switch & Flex, VHF, 6F
25	1405610D01	Insulator, Spacer		2805551D03	Plug (Low & Medium Power)		NLD6901A	Switch & Flex, VHF, 8F
26	4205506C01	Strain Relief, Snap In					NLE8382A	Switch & Flex, UHF, 4F
27			56	0305480E01	Setscrew			(High Power)
28	6405683F01	Plate, Nut	57	0705770M01	Clip Mounting		NLE8392A	Switch & Flex, UHF, 6F
29	0105952E63	Switch (S501-S301)	58	7582745J02	Pad Pressure			(High Power)
30	RPX4253A	Resistor (R308)	59	5982575J02	Microphone (With .036" center hole)		NLE8402A	Switch & Flex, UHF, 8F
31	4005190D01	Switch (S303)						(High Power)
32	4205405C01	Seal		5982575J03	Microphone (Without .036" center hole)	96	7505890C01	Pad, Digital P1 Contour
34	3205295F01	Gasket	60	3205468C01	Gasket, Microphone	97	3205163E01	Boot
35	0905537F02	Jack			(Low & Medium Power)	98	1405576E02	Insulator (330)
36	1805430C02	Resistor		1405445G02	Gasket, Microphone		1405576E03	Insulator (340)
37	NLN8790A	Front Cover (320)			(High Power)		1405576E04	Insulator (350)
	NLN7420A	Front Cover (330)	61	4305467C02	Spacer Standoff		1405576E05	Insulator (360)
	NLN7421A	Front Cover (340)	62	0305480E01	Screw	99	0405248E01	Washer
	NLN7422A	Front Cover (350)	63	5405511C01	Label Knob, Vol. Control	100	3705144E01	Sound pipe (High Power)
	NLN7423A	Front Cover (360)	64	5405511C03	Label, Knob (1 Freq. models)	101	4705143E01	Tubing, Flexible
	NLN8796A	Front Cover (330 High Power)						(High Power)
	NLN7424A	Front Cover (340 High Power)		3305484G01	Label, Knob	102	7505705D01	Pad
	NLN7425A	Front Cover (350 High Power)			(2 Freq. models)	103	0405757E01	Seal
	NLN7426A	Front Cover (360 High Power)				104	0405342C02	Washer
						105	0405757E02	Seal
						106	ST1179	Tool Module Pusher
						107	0483799H06	Washer
38	7505589E03	Pad			(6 Freq. models)	108	0405342C03	Washer
39	425410C01	Clip Fuse				109	4205383F01	Plug
40	4605461C01	Stud	65	3604410C01	Knob	111	0200120487	Nut, hex



Zu beziehen über :

www.oppermann-telekom.de

Jan Oppermann
Hauptstraße 34a
D-06507 Friedrichsbrunn/Harz

Telefon :
039487-552

Fax :
039487-236